



de Montageanleitung
en Mounting instructions
fr Instructions de montage
sv Monteringsinstruktion
nl Montage-aanwijzing
it Istruzioni di montaggio
fi Asennusohje
es Instrucciones de montaje
da Monteringsvejledning

QPM11...
QPM21...




G	AC 24 V ±20 % / DC 15...35 V	B	
G0	GND	M	
U...	DC 0...10 V / 0...5	BS	
I ...	DC 4...20 mA	MS	
G...	DC 13,5...35 V		
C +	com		
C -	com		


QPM1100




QPM2100




QPM2102 QPM2102D







QPM2160 QPM2160D



QPM2162 QPM2162D



QPM2180



Masse in mm Dimensions en mm Mål i mm Afmetingen in mm Mitat mm
Dimensions in mm Dimensiones en mm Mått i mm Dimensioni in mm